

# **FURUNO**

# **INSTALLATION MANUAL**

**MARINE RADAR**

**MODEL FR-1505/1510/1525 MARK-2**



**FURUNO ELECTRIC CO., LTD.**  
**NISHINOMIYA, JAPAN**

©FURUNO ELECTRIC CO., LTD.

9-52, Ashihara-cho,  
Nishinomiya, Japan 662

Telephone: 0798-65-2111  
Telefax: 0798-65-4200

All rights reserved.

Printed in Japan

•Your Local Agent/Dealer

FIRST EDITION : OCT 1994  
H : AUG. 19, 1997

(TATA)

PUB. No. IME-33960-H  
FR-1500 MARK-2 SER.



\* 0 0 0 8 0 6 2 7 9 0 0 \*



# SAFETY INSTRUCTION

"NOTIICE", "CAUTION" and "WARNING" notices appear throughout this manual. It is the responsibility of the installer of the equipment to read, understand and follow these notices. If you have any questions regarding these safety instructions, please contact a FURUNO agent or dealer.



## WARNING

This notice indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



## CAUTION

This notice indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or property damage.

## NOTICE

This notice indicates an unsafe practice which, if not avoided, could result in property damage or equipment malfunction.



# WARNING



**Hazardous voltage.  
Can shock, burn, or cause death.**

Only qualified personnel should work in the unit.

**Turn off the power at the ship's mains switchboard before beginning the installation. Post a warning sign near the switchboard to ensure the power will not be applied while the radar system is being installed.**

Electrical shock, fire, serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.



**Turn off the radar power switch before working on the antenna unit. Post a warning sign near the switch to ensure it will not be turned on while the antenna unit is being installed.**

Serious injury or death can result if the radiator starts rotating and strikes someone near the scanner unit.



**Wear a safety belt and hard hat when working on the antenna unit.**

Serious injury or death can result if someone falls from the scanner mast.



# WARNING



## Radio Frequency Radiation Hazard

The radar antenna emits electromagnetic radio frequency (RF) energy which can be harmful, particularly to your eyes. Never look directly into the antenna aperture from a close distance while the radar is in operation or expose yourself to the transmitting antenna at a close distance.

Distances at which RF radiation levels of 100 and 10 W/m exist are;

Model	Radiation level	XN2	XN3	XN3A	XN4A
FR-1505 M2	10W/m	Nowhere			
	1W/m	5m	4m	4m	4m
FR-1510 M2	10W/m	0.5m	—	—	—
	1W/m	9m	9m	9m	9m
FR-1525 M2	10W/m	4m	3m	3m	3m
	1W/m	15m	15m	15m	15m

**NOTE:** When the antenna is installed at a close distance in front of the wheelhouse, transmission can be stopped within a certain sector of revolution.



## CAUTION



**Ground both the display unit and the antenna unit.**

Ungrounded equipment can give off or receive interference or cause electrical shock.

**Confirm that the power supply voltage is compatible with the voltage rating of the equipment.**

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the display unit.

**Use only the supplied power cable.**

Use of other power cables (particularly cables whose diameter is smaller than the supplied cable) can cause fire or short circuit.

**Use the correct fuse.**

Use of a wrong fuse can cause fire or equipment damage.

## NOTICE

**The installation must be done by a FURUNO representative or suitably qualified radar technician.**

Authorities require this.

**The mounting location must satisfy the following conditions:**

- Useable temperature: -15°C to 55°C
- Out of direct sunlight
- Away from air conditioner vents
- Well ventilated

**Observe the compass safe distances to prevent deviation of a magnetic compass.**

	Standard compass	Steering compass
Display Unit	1.7 m	1.10 m
Scanner Unit	1.50 (3.4) m	0.90 (2.2) m

( ) : 1525M2

**Keep magnets and magnetic fields away from the equipment.**

Magnetic fields will distort the picture and can cause equipment malfunction. Be sure the unit is well away from equipment which gives off magnetic fields (speaker, power transformer, etc.).



# TABLE OF CONTENTS

## **EQUIPMENT LISTS**

**vii**

## **SYSTEM CONFIGURATION**

**xi**

## **MOUNTING OF UNITS**

**1**

Scanner Unit Installation .....	1
Mounting .....	2
Display Unit Installation .....	2
Siting considerations .....	2
Tabletop mounting .....	3
Overhead mounting .....	3
Installation of hand grips (option) .....	3

## **WIRING**

**4**

Scanner Unit Wiring .....	4
Handling the transceiver unit .....	4
Wiring .....	4
Fabricating signal cable RW-3839 .....	5
Display Unit Wiring .....	6
Fabricating the power cable CVV-S 8 x 2C (optional supply) .....	6
Wiring procedure .....	6

## **EXTERNAL SIGNAL INPUT/OUTPUT**

**7**

Input from External Equipment .....	7
Output to External Equipment .....	8
Connection of external speaker, buzzer .....	9
NMEA I/O data .....	10

## **CHANGING POWER SPECIFICATIONS**

**11**

## **ADJUSTMENT**

**12**

Initial, Installation Menus .....	12
Working With the INSTALL Menus .....	14
1. Tuning the Receiver .....	14
2. Sweep Timing Adjustment .....	14
3. Video Amplifier Input Level Adjustment .....	14
4. Main Bang Suppression (MBS) .....	15
5. Heading Alignment .....	15
6. STC Curve Adjustment .....	15
7. Presetting the FUNCTION key .....	15

8. Preventing Transmission in an Area .....	11
9. Selecting Navigator .....	16
10. Other Items on the INSTALL Menus .....	16
Installation Checklist .....	17

---

## **INSTALLATION OF GC-8A (option) 18**

---

Installation Kit .....	18
Installation and Connection .....	18
Using an external power supply .....	19
Confirming Gyrocompass Specifications .....	19
Changing Settings of the GYRO CONVERTER Board .....	20
Setting of Heading .....	21

---

## **OUTLINE DRAWINGS D-1**

---

Display Unit (RDP-111) .....	D-1
Scanner Unit (XN1/2/3) .....	D-2
Scanner Unit (XN3A/4A, type RSB0063/C2P7N2N/C2P8N2N) .....	D-3
Scanner Unit (XN2/3) .....	D-4
Scanner Unit (XN3A/4A, type RSB0014/RSB0064) .....	D-5
Scanner Unit (assembling XN1/2/3) .....	D-6
Scanner Unit (assembling XN3A/4A) .....	D-7

---

## **SCHEMATIC DIGRAMS S-1**

---

Interconnection Diagram .....	S-1
Display Unit, General .....	S-2
Scanner Unit (C2P7N2N, 24 rpm; RSB0063, 36 rpm) .....	S-3
Scanner Unit (RSB0014, 24 rpm; RSB0064, 36 rpm) .....	S-4



# EQUIPMENT LISTS

## Complete Set

Name			Type	Code No.	Qty	Remarks		
S C A N N E R  U N I T	FR-1505 MARK-2	24 rpm	XN2-C2P7N2N-043-S		1	123 cm radiator		
			XN3-C2P7N2N-043-S			200 cm radiator		
			XN3A-C2P7N2N-043			200 cm radiator		
		36 rpm	XN2-RSB0063-043-S			123 cm radiator		
			XN3-RSB0063-043-S			200 cm radiator		
			XN3A-RSB0063-043-S			200 cm radiator		
		FR-1510 MARK-2	24 rpm	XN2-C2P7N2N-044-S			1	123 cm radiator
				XN3-C2P7N2N-044-S				200 cm radiator
				XN3A-C2P7N2N-044-S				200 cm radiator
	XN4A-C2P7N2N-044-S				240 cm radiator			
	36 rpm		XN2-RSB0063-044-S		123 cm radiator			
			XN3-RSB0063-044-S		200 cm radiator			
			XN3A-RSB0063-044-S		200 cm radiator			
			XN4A-RSB0063-044-S		240 cm radiator			
	FR-1525 MARK-2		24 rpm	XN2-RSB0014-045-S		1		123 cm radiator
		XN3-RSB0014-045-S			200 cm radiator			
		XN3A-RSB0014-045-S			200 cm radiator			
		XN4A-RSB0014-045-S			240 cm radiator			
		36 rpm	XN2-RSB0064-045-S		123 cm radiator			
			XN3-RSB0064-045-S		200 cm radiator			
			XN3A-RSB0064-045-S		200 cm radiator			
			XN4A-RSB0064-045-S		240 cm radiator			
Signal Cable Assy. (Selectable)			S03-53-X		1	15m, 20m, 25m, or 30m		
			ML connector Assy.	008-461-500		For HV line		
Display Unit	FR-1505 MARK-2	RDP-111-A		1				
	FR-1510 MARK-2	RDP-111-B		1				
	FR-1525 MARK-2	RDP-111-C		1				
Installation Materials			CP03-14201 (display)	008-455-250	1 set	See respective installation materials list.		
			CP03-00820 (scanner)	008-215-990	1 set			
Accessories			FP03-05600	008-102-930	1 set	Hood assy.		
Spare Parts			SP03-11100	000-085-937	1 set	For display unit		
			SP03-11102	000-455-240	1 set	For scanner unit		
			SP03-09000	000-419-080	1 set	For GC-8A		

### ***Optional Supply & Equipment to be Connected***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Remarks</b>
Auto Plotter	ARP-15	008-455-710	
Video Plotter	RP-15		
Gyro Converter	GC-8A	008-461-560	
Signal Cable	S03-55-5	008-455-160	5pin XH, factory wired 5 m
Interswitch	RJ-2	000-030-062	
Rectifier	RU 1746B-2	000-030-439	110 VAC
		000-430-440	220 VAC
Power Cable	CVV-S 8 x 2C, 15 m	000-560-634	
Color Display	CD-140/141		
Video Plotter	GD-500/500 M2		
Remote Display	FMD-8000(LOG)/8010		
External Buzzer	OP03-21	000-030-097	
Handgrip	OP03-70	008-423-420	
Filter	OP03-30	008-102-200	
Dust Cover	03-024-0401	000-801-325	

### ***Accessories***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Qty</b>	<b>Remarks</b>
Hood Assy.	FP03-02310	008-102-930	1	

### ***Spare Parts for Display Unit***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Qty</b>	<b>Remarks</b>
Fuse	FGBO-A 3A 125VAC	000-549-063	2	For CRT
Fuse	FGBO 10A 125VAC	000-549-065	2	For 24/32VDC
Fuse	FGBO 20A 125VAC	000-549-015	2	For 12VDC

### ***Spare Parts for Scanner Unit***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Qty</b>	<b>Remarks</b>
Carbon Brush	MG120-5 x 6 x 11D8G	000-631-716	2	

### ***Installation Materials for Display Unit***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Qty</b>	<b>Remarks</b>
Signal cable assy 15m	S03-53-15	008-455-070	1	Select one. Connector at one end, no armor, ø18.4. (standard length: 15m)
Signal cable assy 20m	S03-53-20	008-455-080		
Signal cable assy 25m	S03-53-25	008-455-090		
Signal cable assy 30m	S03-53-30	008-455-100		
Crimp-on lug	FV2-4	000-538-118	4	For power cable
	8NK4	000-538-180	6	
Panhead Screw	M3 x 10 C2700W MBN12	000-881-105	2	For fixing DJ conn. of display unit
XH Connector Assy.	03-1768(3P)	008-459-090	1	For connection of log
XH Connector Assy.	03-1798(4P)	008-463-400	1	For connection of radar buoy
XH Connector Assy.	03-1796(5P)	008-462-830	4	NAV I/O, E/S, AD-100


### ***Installation Materials for Scanner Unit***

<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Qty</b>	<b>Remarks</b>
Grounding Wire	RW-4747 1 = 320 mm	000-566-000	1	For grounding scanner
Hex Bolt	M6 x 25 SUS304	000-862-180	1	For mounting grounding wire
	M12 x 60 SUS304	000-862-191	4	For mounting scanner
Hex Nut	M6 SUS304	000-863-109	1	For mounting grounding wire
	M12 SUS304	000-863-112	4	For mounting scanner
Flat Washer	M6 SUS304	000-864-129	3	For mounting grounding wire
	M12 SUS304	000-863-132	4	For mounting scanner
Spring Washer	M6 SUS304	000-864-260	1	For mounting grounding wire
	M12 SUS304	000-864-263	4	For mounting scanner
Crimp-on Lug	FVD1.25-3, red	000-116-634	1	For coaxial cable (2C-2V)
	FV1.25-L3, red	000-538-111	29	For scanner terminal board
	FV2-4, blue	000-538-118	1	For scanner terminal board
	8NK4	000-538-180	2	For connecting DC power
Corrosion-proof Rubber Mat	03-001-3001-0 CR	300-130-010	1	For preventing electrolytic corrosion
Seal Washer	03-001-3002-0	300-130-020	4	For preventing electrolytic corrosion

## ***Cabling for Feeding Data to/from Display Unit***

<b>Equipment to Connect</b>	<b>Cable Required</b>	<b>Cable Assy. Type</b>	<b>Cable Assy. Code No.</b>	<b>Remarks</b>
Navigator	CO-SPEVV-SB-C 0.2 x 2P (5P)	S-03-55-5	008-455-160	NMEA data input, 5 pin XH, factory wired
Gyrocompass	250V-MPYC (Y)-5			local supply
AD-10S, AD-100	CO-SPEVV-SB-C 0.2 x 2P (5P)	S-03-55-5	008-455-160	
Speed log	250V-MPYC (Y)-1.25			local supply
Slave display	RW-4865 * 5M *	S03-22-5	008-239-140	Supplied with slave display installation materials
	RW-4865 * 10M *	S03-22-10	008-239-150	
	RW-4865 * 15M *	S03-22-15	008-239-160	
Remote display				supplied with FMD-1800
Water temp, depth, HDG data (NMEA)	CO-SPEVV-SB-C 0.2 X 2P (5P)	S03-55-5	008-455-160	5 pin XH, factory wired

# SYSTEM CONFIGURATION



**NOTE:** Dashed lines indicate equipment which can be connected.

# MOUNTING OF UNITS

## Scanner Unit Installation

### Before beginning the installation...

- Wear a helmet and safety belt when working on the mast.
- Secure an "off limits" area to prevent injury due to falling objects.
- DO NOT lift the scanner unit by the radiator. Use the lifting fixtures on the unit.
- DO NOT paint the radiator surface.
- Observe the following compass safe distances to prevent deviation of the magnetic compass;

*Table 1 Scanner unit compass safe distances*

Compass	FR-1505/1510 M2	FR-1525 M2
Standard	1.50 meters	2.5 meters
Steering	0.90 meters	2.0 meters

- Distances at which radiation level of 10 and 1 W/m<sup>2</sup> exist are;

*Table 2 Radiation levels*

Model	Radiation level	XN2	XN3	XN3A	XN4A
FR-1505 M2	10W/m <sup>2</sup>	Nowhere			
	1W/m <sup>2</sup>	5m	4m	4m	4m
FR-1510 M2	10W/m <sup>2</sup>	0.5m	—	—	—
	1W/m <sup>2</sup>	9m	9m	9m	9m
FR-1525 M2	10W/m <sup>2</sup>	4m	3m	3m	3m
	1W/m <sup>2</sup>	15m	15m	15m	15m

### Siting considerations


- The scanner unit is generally installed either on top of the wheelhouse or on the radar mast on an appropriate platform, parallel with ship's keel line. It should be placed where there is a good all-round view with, as far as possible, no part of the ship's superstructure or rigging within the scanner's vertical beamwidth (XN2/3, 25°; XN3A/4A, 20°)
- Five fixing holes are required in the scanner unit platform: Four ø15 mm for mounting of the scanner unit and one ø50 mm for the signal cable.
- If there is a radio direction finder on the vessel, locate its antenna clear of the scanner unit, to prevent interference to the direction finder.

- Deposits and fumes from a funnel or other exhaust vent can adversely affect the aerial performance and hot gases tends to distort the radiator portion. The scanner unit must not be mounted where it may be subjected to temperatures in excess of 70°C.

### Assembling

The procedure which follows provides general scanner unit assembly instructions. Assemble the unit by referring to the scanner unit outline drawing at the end of this manual.

- 1) Coat the waveguide flange with silicone sealant as shown in Figure 1.



Evenly coat the waveguide flange with silicone sealant. Apply just enough so the sealant oozes out when the bolts are tightened. Be sure no sealant contacts the choke groove and waveguide.

*Figure 1 How to coat the waveguide flange with silicone sealant*

- 2) Fix the feeder waveguide to the rotary joint.
- 3) Loosely fasten the antenna radiator to the rotary joint.
- 4) Fasten the feeder waveguide to the antenna radiator.
- 5) Fasten the feeder waveguide to the base of the antenna radiator.
- 6) Fasten the antenna radiator to the antenna bracket.

## Mounting

- 1) Lay the corrosion-proof rubber mat (supplied) on the mounting platform.




Figure 2 Location of bow mark, steps in mounting the scanner unit

- 2) Hoist the scanner unit to the mounting location. Orient the scanner unit so the bow mark on the scanner unit faces ship's bow.




Figure 3 Location of lifting fixtures

- 3) Fasten the scanner unit to the mounting platform with M12 x 60 hex bolts, seal washers and nuts.




Figure 4 How to fasten scanner unit to mounting platform

- 4) Prepare ground point in mounting platform (within 300 mm of ground terminal on scanner unit) using M6 x 25 bolt, nut and flat washer.

- 5) Run the ground wire (RW-4747, 320 mm) between the ground terminal and ground point.
- 6) Coat ground terminal and ground point with silicone sealant as shown in Figure 5.




Figure 5 How to coat ground point and ground terminal with silicone sealant

## Display Unit Installation

### Siting considerations

- The display unit can be mounted on a tabletop, a bulkhead or on the overhead. Install it where it can be viewed and operated conveniently, but where it is protected from being sprayed or immersed in salt or fresh water.
- Observe the following display unit compass safe distances to prevent deviation of the magnetic compass;

Table 3 Display unit compass safe distances

Compass	FR-1505/1510/1525 MARK-2
Standard	1.70 meters
Steering	1.10 meters

- The display unit should be oriented so that you can view the screen while facing towards the bow. This will make determination of your position easier.

- The mounting location must be strong enough to support the display unit under vibration conditions normally encountered on the vessel. If necessary reinforce the mounting location.
- Determine the mounting location considering the distance between the scanner unit and the display unit. (The maximum length of the signal cable is 60 meters.)
- Make sure you allow enough clearance to get to the connectors behind the unit. Leave at least a foot or so of "service loop" in cables so that it can be pulled forward for servicing or easy removal of the connectors.

### Tabletop mounting

- 1) Loosen the two M8 x 40 bolts at the front of the display unit. Remove the fixing plate.
- 2) Mark screws locations in the tabletop by using the fixing plate as a template. **For mounting by bolts and nuts**, drill four holes of 12 mm diameter in the tabletop.
- 3) Secure the fixing plate to the tabletop by tapping screws or M10 bolts, nuts and washers.
- 4) Lay the display unit on the fixing plate. Secure it with the two M8 x 40 bolts loosened in step 1.




Figure 6 Tabletop mounting

### Overhead mounting

- 1) Referring to Figure 7, change the location of the fixing plate, mounting base, bottom plate and cover to mount the unit on the overhead.




Figure 7 Display unit bulkhead or overhead mounting

### Installation of hand grips (option)

Remove black cosmetic caps on both sides of front panel. Fasten hand grips.




Figure 8 Hand grips



# WIRING

## Scanner Unit Wiring

### Handling the transceiver unit

The transceiver unit contains the magnetron. The magnetron will demagnetize if it contacts magnetic material. When dismantling the transceiver, lay it atop non-magnetic material or lay it on its side, to prevent demagnetization. See Figure 9.




Figure 9 How to set the transceiver to prevent magnetron demagnetization

### Wiring

- 1) Open the scanner unit cover.
- 2) Disconnect plugs P801 and P601.
- 3) Unfasten the transceiver unit fixing bolts and dismount the transceiver unit from the scanner unit.




Figure 10 Transceiver unit, front view

- 4) Unfasten four fixing bolts on the cable gland at the base of the scanner unit. Remove clamping ring, rubber gasket and flat washers (2) from cable gland. See Figure 11.
- 5) Pass the signal cable through the cable entry hole in the scanner unit mounting platform. Shorten the cable so about 80 cm of it protrudes out of the cable gland.
- 6) Slide the flat washer, rubber gasket, flat washer and clamping ring onto the cable in that order.




Figure 11 Passing cable gland assembly materials onto signal cable

- 7) Fabricate the signal cable as shown on page 5. Make the length of the cable a little longer than necessary to prevent damage to the coaxial cable.
- 8) Pass the outer and inner shields between the signal cable and the clamping ring. Fasten the cable gland.




Figure 12 Passing shields between clamping ring and signal cable

- 9) Connect the signal cable to the terminal board RTB801 by referring to the interconnection diagram.
- 10) Bind cores with cable ties as shown in Figure 13.




Figure 13 Scanner unit, rear view, cover opened

- 11) Install the transceiver unit. Connect plugs P801 and P601. Fasten the shields (inner and outer combined) to the ground terminal on the transceiver unit. See Figure 10 for location of ground terminal.
- 12) If the scanner is mounted leftward of the ship's bow line by up to 2°, turn on reed switch S901. (It is electrically connected to P902 #1 and #2 on the BRG SIG GEN Board MP-3795).
- 13) Confirm that all screws are tightened and all wiring is properly made.
- 14) Coat waterproofing gasket, bolts and tapping holes of scanner unit with silicone grease as shown in Figure 14.




Figure 14 Coating scanner unit cover with silicone grease

- 15) Confirm that the waterproofing gasket is seated as shown in Figure 15.




Figure 15 Seating of waterproofing gasket

## Fabricating signal cable RW-3839

- 1) Remove the vinyl sheath by 450 mm.
- 2) Slide flat washers (2), rubber gasket, washer, and clamping ring onto the cable.
- 3) Unravel the outer shield to expose the cores in the outer layer.
- 4) Unravel the inner shield to expose the cores in the inner layer. Label all inner cores to aid in later identification.
- 5) Trim each core (except coaxial wire) considering the distance to their terminals on the terminal board.
- 6) Trim the inner and outer shields leaving 50 mm each. Combine shields and attach crimp on-lug FV2-4 (blue, ø4).
- 7) Remove core insulation by 6 mm approximately. Fix crimp-on lug FV1.25-L3 (red, ø3) to each core.
- 8) Fabricate the coaxial cable. Make the length 10 mm longer than the shield to prevent wire strain. Attach crimp-on lug FV1.25-3 (red, ø3).




Figure 16 Fabricating signal cable RW-3839

# Display Unit Wiring

## Overview

At least two cables are terminated at the display unit: the signal cable and the power cable. The signal cable, which is available in lengths of 15 meters, 20 meters, 25 meters or 30 meters, comes prefitted with a connector for connection to the display unit.

Proper grounding of cables cannot be stressed enough; be sure to ground the shield of cables by the cable clamp.

## Fabricating the power cable CVV-S 8 x 2C (optional supply)

- 1) Remove the vinyl sheath by 40 mm.
- 2) Unravel the braided shield to expose the cores.
- 3) Remove insulation of cores by about 10 mm.
- 4) Fix crimp-on lugs to the cores and braided shield.




Figure 17 How to fabricate the power cable (CVV-S 8 x 2C)

## Wiring procedure




Figure 18 Display unit, rear view, cover removed

- 1) Remove the display unit cover.
- 2) Dismount the clamping plate from the cable clamp by loosening two screws.

- 3) Lay the signal cable and power cable inside the cable clamp. Fasten the clamping plate to the cable clamp by using two M4 x 12 screws. If optional equipment are connected, secure the clamping plate by using two M6 x 30 bolts.




Figure 19 Display unit, rear view

- 4) Connect the power cable and signal cable by referring to the interconnection diagram. Fasten shields to chassis.
- 5) Run a ground wire (IV-8 sq, or equivalent) from the ground terminal to nearest ground point.




Figure 20 Exploded view of A in Figure 19

It is recommended to seal the cable gland (with aluminum tape, etc.) to keep foreign objects out of the display unit.




Figure 21 Sealing the cable gland

# EXTERNAL SIGNAL INPUT/OUTPUT

## Input from External Equipment

As shown in Table 4, the FR-1500 series accepts inputs from a wide variety of equipment. All external equipment are connected to the SPU Board, which is near the DJ connector at the rear of the display unit. A signal cable for connection to the asterisk-marked connectors in the figure below can be supplied. It is S03-55-5 (XHP-5 5P connector at one end, armor, vinyl sheath w/2-pair cable, 5 meters).

### XHP-5 connector wiring

Terminal no.	Wire color	
1	BROWN	pair
2	RED	
3	ORANGE	pair
4	YELLOW	
5	BLACK	





Figure 22a Location of connectors on SPU Board

*Table 4 External signal input connector (SPU Board)*


Signal	Connector	Connector no.	Connector type	Equipment (example)	Remarks
Heading signal	to GC-8	J207 (*1)	XH, 6 pin	GC-8A	UP, DOWN, HOLD
	from GC-8	J206	XH, 5 pin	AD-10S, AD-100, GC-8A	AD-10 format
	HDG IN	J213	XH, 5 pin	C-2000	HDG (NMEA format)
Speed log signal	LOG	J210	XH, 3 pin	DS-70, DS-30, MF-220, CI-60	200 pulses/nm, etc.
Nav data (L/L, wpt, time, TD, course, water temp., depth)	NAV IN	J203	XH, 5 pin	GP-3100, GP-50M2, GP-188, FCV series, T-2000, TI-20	(*2)
Slave display input signal	—	DJ1	28 pin		When used to connect a slave display, input heading, bearing, video and trigger signals through DJ connector.
Radar buoy signal	for R. BUOY	J212	XH, 4 pin		
Heading, water temp., depth	HDG IN	J213	XH, 5 pin	T-2000, TI-20	(*3)

\*1 Requires PC board 64P1106 (option).

\*2 Requires interface (IF-2901, etc.) to input position, water temperature and depth.

\*3 HDG IN connector can accept water temperature or depth data (NMEA) in lieu of heading signal.

## Output to External Equipment



*Figure 22b Location of connectors on SPU Board*

*Table 5 External signal output connector (SPU Board)*


Signal	Connector	Connector no.	Connector type	Equipment (example)	Remarks
ARPA signal	to ARPA	J205	NH, 8 pin	FA-2800, etc.	heading marker, bearing, video, tx trigger
Slave display signal	to SLAVE	J204	NH, 8 pin	CD-140, CD-141, GD-500, FMD-800, FMD-8000 (*1)	heading marker, bearing, video, true trigger
Alarm signal	EXT ALARM	J211	NH, 3 pin	OP03-21-3	Buzzer drive signal
				Speaker w/amp	Speaker signal
Monitor signal	to VTR	J208	NH, 6 pin	FMD-1800 (*2)	Horizontal synch, vertical synch, video (NTSC format)
Radar signal (serial data)	NAV OUT	J209	XH, 5 pin	To navigator (plotter)	NMEA 0183 \$RATLL \$RARSD

\*1 Display unit for FR-1505/1510/1525 M2, FR-7041/7111 can be used as slave display unit.

\*2 Display horizontal and vertical are reversed.

### Connection of external speaker, buzzer

An external speaker or buzzer can be connected to this radar via an amplifier circuit (local supply), as shown in the figure below. Ground the amplifier to nearby connector's ground terminal.



*Figure 23 Connection of external speaker or buzzer to the SPU Board*

## NMEA I/O data

The FR-1500 series accepts the following nav data input/output sentences.

### Receivable NMEA 0183 sentences

Input/Output	Receive sentence
Speed	RMA>RMC>VTG>VHW
Heading (true)	HDT>VHW>HDG>HDM
Heading (relative)	RMA>RMC>VTG
Course (true)	RMA>RMC>VTG
Course (magnetic)	VTG>RMA>RMC
Waypoint (range/bearing)	RMB>BWC>BWR
Ship's position	RMA>RMC>GLL
Loran TD	RMA>GLC>GTD
Time	ZDA
Water temperature	MDA>MTW

### Transmittable NMEA 0183 sentences

Input/Output	Transmit sentence
Target position (cursor latitude and longitude)	RAATLL
Radar system data *	RARSD
Target message ** when equipped w/ARP-15	RATTM

\* Origin mark range and bearing, EBL bearing, VRM range, cursor range and bearing, etc.

\*\* Target no., range, bearing, course, speed, CPA, TCPA, etc. Outputted from J2 #1/#2 on the ARP Board.

# CHANGING POWER SPECIFICATIONS

This radar can operate by either 12V, 24V or 32V power. (12V operation is available for FR-1505/1510 M2, but is not available with the FR-1525 M2 or the 36 rpm scanner unit.) Power specification can be changed from 12V to 24V/32V and vice versa by jumper wire JP1 and the power fuse F1351.

## Input voltage rating (at terminal board in display unit)

12V DC: 10.2 to 15.0 V DC

24V/32V DC: 20.4 to 40.0V DC

## Procedure

- 1) Remove the display cover.
- 2) Remove rear panel of display unit by unfastening five screws. Unfasten three screws securing the POWER Board.




Figure 24 Display unit, rear view

- 3) Unplug connectors on the POWER Board and remove the board.

- 4) Attach jumper wires as shown in below. Jumper JP1 is on underside of the transformer.

### 12V DC spec.

Attach jumper wires between ①-②, ③-④, ⑤-⑥, and ⑦-⑧.

### 24V/32V DC spec.

Attach jumper wires between ②-③ and ⑥-⑦.




Figure 25 Location of jumper JP1 on transformer

- 5) Change fuse as follows.

12V DC spec.: 20A

24V/32V DC spec.: 10A

- 6) Reassemble the power section.



# ADJUSTMENT

## Initial, Installation Menus

Many presettings and adjustments are done on the INITIAL and INSTALL menus. Below and on the next page are menu trees for these menus. Factory settings shown in bold.




Figure 26 INITIAL menus




Figure 27 *INSTALL* menus

## **Working With the INSTALL Menus**

---

### **Accessing the INSTALL menus**

While pressing and holding down the **GAIN** control, turn on the power.

### **Displaying the INSTALL menus**

Press the **MENU** key about two seconds to display the **INITIAL** menu. Select **INSTALL** on the **INITIAL2** menu and press the **ENTER** key.

### **Selecting items on menus**

- 1) Operate the VRM or EBL encoder to select menu.
- 2) Press the **ENTER** key.
- 3) Operate the VRM or EBL encoder to change setting.
- 4) Press the **ENTER** key.

### **Closing the menu**

Press the **MENU** key.

### **Changing pages**

**Next page:** Place cursor on ↓ and press the **ENTER** key.

**Previous page:** Place cursor on ↑ and press the **ENTER** key.

### **Clearing wrong data**

Press the **CLEAR** key.

## **1. Tuning the Receiver**

---

### **Initial setting**


With the radar transmitting, do the following:

On the **INITIAL1** menu, select **TUNE SET** and press the **ENTER** key. The unit automatically tunes the receiver, displaying the indication **AUTO TUNING** at the bottom of the menu while tuning. When tuning is completed, the indication disappears. (This procedure records both peak value for the **TUNE** indicator and automatic coarse tuning.)

## **2. Sweep Timing Adjustment**

---

Sweep timing depends on the length of the signal cable (between the display unit and the scanner unit). Adjust it as shown in the procedure below to prevent pushing in pulling out of targets as shown in the Figure 28.



*Figure 28 Examples of proper and improper sweep timing*

- 1) Select **TIMING** on the **INSTALL1** menu and press the **ENTER** key.
- 2) Transmit on the 0.125 nautical mile range, and visually select a target which forms right angles (harbor wall, etc.).
- 4) Operate the VRM encoder to straighten target selected in step 3. For reference, amount "straightened" in nautical miles appears at bottom right side on the display.
- 5) Press the **ENTER** key.

## **3. Video Amplifier Input Level Adjustment**

---

The longer the signal cable the lower the video amplifier level input and thus the smaller targets appear on the display. Do the following to adjust video amplifier level input.

- 1) Transmit on a long range.
- 2) On the **INSTALL1** menu, select **VIDEO** and press the **ENTER** key.

At the bottom of the menu **AUTO ADJ.** appears. The indication disappears when adjustment is completed.

## 4. Main Bang Suppression (MBS)

Main bang, which appears at the display center on short ranges, can be suppressed as follows.

- 1) Transmit on long range about 10 minutes.
- 2) Adjust the gain to show a small amount of noise on the display.
- 3) Change to the 0.125 nautical mile range and adjust the A/C SEA control.
- 4) Select M. BANG on the INSTALL1 menu.
- 5) Press the **ENTER** key.
- 6) Operate the VRM encoder to suppress main bang
- 7) Press the **ENTER** key.

## 5. Heading Alignment

The scanner unit is mounted facing straight ahead in the direction of the bow. Therefore, a small but conspicuous target dead ahead visually should appear on the heading mark. In practice, however, there will be some error on the display because of the difficulty in achieving accurate initial positioning of the scanner unit. Do the following to compensate for error.




Figure 29 Plus heading error




Figure 30 Minus heading error

- 1) Identify a suitable target (by gyrocompass, for example) at a range between 0.125 to 0.25 nautical miles, preferably near the heading mark.
- 3) Open the INSTALL1 menu and select HDG ADJ.
- 4) Press the **ENTER** key.
- 5) Operating the VRM encoder, bisect the target by the EBL. The value at the bottom right of the menu shows antenna position in relation to ship's bow (0°).
- 6) Press the **ENTER** key.

## 6. STC Curve Adjustment

Open the INSTALL1 menu and enter antenna height and best STC curve.

**Antenna height:** Enter antenna height above the waterline as accurately as possible.

**STC curve:** Select STC curve by expected average sea conditions.

## 7. Presetting the FUNCTION key

The **FUNCTION** key provides one-touch adjustment of STC, pulselength, and other controls. Eight types of target setups are available (see Table 6 on next page) and three can be preset on the FUNC KEY menu.

- 1) Press the **FUNCTION** key and select function number (FUNC1, FUNC2, or FUNC3) to set.
- 2) Select FUNC KEY on the main menu.
- 3) Place the cursor on the FUNC SEL.

The (factory) settings of these items may be changed. However, since each item is set considering target objective, any change may prevent obtainment of objective.

To restore factory settings, select appropriate function again and close the menu.

FUNC ( 1 )	
FUNC	
S1	OFF
ECHO AVG	OFF
INTRF	OFF
STRETCH	OFF
A/C AUTO	OFF
NOISE	OFF
P/L SEL	OFF

Figure 31 Function setting display

- 4) Press the **ENTER** key.
- 5) Operate the VRM encoder to select settings.
- 6) Press the **ENTER** key.

To set another function number (2 or 3), erase the menu and then repeat steps 1 to 5.

**NOTE:** When the main menu displays *FUNC KEY\**, this means no function is active and the *FUNCTION* key is inoperative. To select a function, erase the menu and press the *FUNCTION* key.

Table 6 Function objectives

Item	Description
S1 (Short range 1)	Short range navigation (within 1.5 nm); for example, when approaching a harbor.
S2 (Short range 2)	Short range navigation within 3 nm.
S & M (Short and Medium ranges)	General navigation on ranges within 12 nm.
L-ES (Long range-cho Stretch)	Magnify target echoes on 6 nm range and higher ranges.
L-STC (Long range-STC)	Suppress sea surface reflections on 3 nm range and higher ranges.
ES (Echo Stretch)	Magnify target echoes on 1.5 nm range and higher ranges.
B1 (Buoy 1)	Detect echoes from small targets (various buoys, small vessels, floats, etc.) on ranges within 1.5 nm.
B2 (Buoy 2)	Detect small targets on ranges greater than 1.5 nm.

## 8. Preventing Transmission in an Area

When the scanner is installed at a close distance in front of the wheelhouse and this presents an rf radiation hazard, the radar should be set not to transmit within that area. This feature can also be used to prevent transmission in a blind or shadow sector. Two areas can be set.

### Procedure

- 1) Display the **INSTALL2** menu.
- 2) Select **TX STOP**.
- 3) Press the **ENTER** key.
- 4) Select **AREA 1** or **AREA 2**.

- 5) Press the **ENTER** key.
- 6) Enter start of area by operating the VRM encoder.
- 7) Press the **ENTER** key.
- 8) Enter end of area by operating the VRM encoder.
- 9) Press the **ENTER** key.

## Deleting no transmission area

Enter 000° as end of area.

## 9. Selecting Navigator

On the **INITIAL1** menu, select **NAV SEL** and navigator which feeds position data to the radar.

## 10. Other Items on the INSTALL Menus

Table 7 Other items on INSTALL menus

Item, INSTALL menu no.	Description
Alarm level, #2	Set echo strength which will trigger the guard alarm. Note that the <b>HIGH</b> setting can trigger alarm on sea clutter.
Log pulse ratio, #2	Enter log pulse ratio.
Heading sensor, #2	Select heading sensor which feeds heading data to the radar.
Key response, #2	Turn on or off key beep.
Video signal, #2	Normally set to <b>NORMAL</b> .
Own ship data, #2	Turn on <b>SHP GRPH</b> on the <b>INITIAL1</b> menu, and enter own ship data to accurately depict own ship graphic (on the display) on <b>INSTALL2</b> menu.
Transmitting while scanner is stopped, #2	Radar pulses can be transmitted with scanner rotation suspended, for servicing, etc.
Echo averaging and no gyro, #3	Turn off echo averaging when no gyro is connected.
Display unit function, #3	Select function of display unit: main or slave display.

## **Installation Checklist**

After completing the installation, check it for completeness following the checklist shown below. Check asterisk-marked items if they apply to the installation.

- ☐ Tuning circuit adjustment
- ☐ Video level adjustment
- ☐ Main bang suppression
- ☐ Sweep timing adjustment
- ☐ Heading alignment
- ☐ Antenna height selection, STC curve selection
- ☐ FUNCTION key presetting
- ☐ \*Entry of area of no transmission
- ☐ \*Setting of GC-8A
- ☐ \*Selection of navigator
- ☐ Setting up of INITIAL menus
- ☐ \*Entry of log pulse ratio
- ☐ \*Selection of heading sensor
- ☐ Disabling of echo averaging when no gyrocompass is connected
- ☐ Setting up of INSTALL menus
- ☐ \*Confirmation of heading set (coincidence with gyro reading)

# INSTALLATION OF GC-8A (OPTION)

## Installation Kit


*Table 8 Contents of GC-8A installation kit*

Name	Type	Code No.	Qty
GYRO CONVERTER Board	64P1106	004-412-200	1
Spacer	SQ-10	000-801-678	4
Washerhead Screw	M3 x 8	008-456-404	4
PH-XH Connector	03-1761 (14P-6P)	008-456-130	1
NH-XH Connector	03-1762 (5P-5P)	008-456-140	1
Label	64-014-2021-1	100-132-701	1
VH Connector Assy.	03-1763 (5P)	008-456-150	1
VH Connector Assy.	03-1764 (3P)	008-456-160	1
Spare Fuses (4 pcs.)	FGMB 2A 250V	000-122-000	4

**NOTE:** Other parts may be contained with the installation kit; use only the parts noted in Table 8. Unrelated parts may be discarded.

## Installation and Connection

- 1) Remove rear cover.
- 2) Attach spacers as shown below.



*Figure 32 Display unit, rear view*

- 3) Install the GYRO CONVERTER Board (64P1106).
- 4) Connect the GYRO CONVERTER Board to the SPU Board as follows;

**GYRO CONV. Board (64P1106)**      **SPU Board (03P2159)**

J1 (14P) ↔ J207 (6P)  
J7 (5P) ↔ J206 (5P)

- 5) Set DIP switches and jumper wires on the GYRO CONVERTER Board according to gyrocompass. See the next page.
- 6) Solder the connection cable from the gyrocompass to the VH connector assembly. Connect the VH connector assembly to the GYRO CONVERTER Board as follows;

Connector		Step type	Synchro type
J4	#1	S1	S1
	#2	S2	S2
	#3	S3	S3
	#4		
	#5	F. G.	F. G.
J5	#1	—	R2
	#2	COM	R1
	#3	F. G.	F. G.

- 7) Attach instruction label (supplied) to rear side of rear cover for GYRO CONVERTER Board.

## Using an external power supply

An external power supply is necessary when the repeater signal is step type and the step voltage is less than 20V, or when the gyrocompass cannot deliver more than 5W of power. Connect an external power supply to the GYRO CONVERTER Board as shown below.





Figure 33 Connection of external power supply to the GYRO CONVERTER Board

## Confirming Gyrocompass Specifications

Follow the flow chart at the bottom of this page to confirm gyrocompass specifications.





## Changing Settings of the GYRO CONVERTER Board

Set the DIP switches and jumper wires on the GYRO CONVERTER Board by specification of gyrocompass.

### 1) Gyro type

Gyro	SW 1-4	SW 1-5	SW 1-6	JP1
AC synchro	OFF	OFF	OFF	#1, #2, #3
DC synchro	OFF	OFF	OFF	#2, #3, #4
DC step	ON	OFF	OFF	#4, #5, #6
Full-wave pulsating current	OFF	ON	OFF	#4, #5, #6
Half-wave pulsating current	ON	ON	OFF	#4, #5, #6

### 2) Frequency

Frequency	SW 1-7	SW 1-8	Remarks
50/60Hz	OFF	OFF	AC synchro pulsating current
400Hz	ON	OFF	AC synchro pulsating current
500Hz	OFF	ON	AC synchro pulsating current
DC	ON	ON	DC synchro DC step

### 3) Rotor voltage (between R1 and R2)

Rotor voltage	SW 2-1	JP3
20V to 45V AC	OFF	#2
30V to 70V AC	OFF	#2
40V to 90V AC	ON	#1
60V to 135V AC	OFF	#1

### 4) Stator voltage (between S1 and S2)

Stator voltage	SW2-2	SW 2-3	JP3
20V to 45V AC, or 20V to 60V DC	ON	OFF	#2
30V to 70V AC, or 40V to 100V DC	OFF	OFF	#2
40V to 90V AC	ON	OFF	#1
60V to 135V AC	OFF	OFF	#1

### 5) Ratio

Ratio	SW1-1	SW 1-2	SW1-3
360x	OFF	OFF	OFF
180x	ON	OFF	OFF
90x	OFF	ON	OFF
36x	ON	ON	OFF

### 6) Supply voltage

Supply voltage	JP4	JP5
20V to 45V AC, or 20V to 60V DC	#2	#2
30V to 135V AC, or 40V to 100V DC	#1	#1

### 7) AD-10 format data transmitting interval

Jumper wires JP6 and JP7 set the data transmitting intervals of data output ports 1 through 6. Two intervals are available: 25msec and 200msec. For radar the interval must be 25msec. For other equipment use 200msec.

### 8) NMEA-0183 data transmitting interval

Set NMEA-0183 data output synchronization (J6).

Tx interval	SW2-4
2 seconds	ON
1 second	OFF

9) Reset the CPU by turning on and off either the power or DIP switch S2-8.

**NOTE:** Sometimes the bearing displayed on the radar is different from that of the gyrocompass despite correct connections and settings. In this case try exchanging two connections among S1, S2 and S3.

## Setting of Heading

Allow the gyrocompass to stabilize and then follow the procedure below.

- 1) Press the **MENU** key.
- 2) Open the **INITIAL1** menu and select **HDG SET**.
- 3) Press the **ENTER** key.
- 4) Operate the **VRM** encoder to set heading.
- 5) Press the **ENTER** key.




Figure 34 GYRO CONVERTER Board (64P1106)

**Table 9 DIP switch and jumper wire settings on the GYRO CONV. Board by make and model of gyrocompass**

Revised at Feb. 1, 1996

Maker	Models	Specification	SW 1-1	SW 1-2	SW 1-3	SW 1-4	SW 1-5	SW 1-6	SW 1-7	SW 1-8	SW 2-1	SW 2-2	SW 2-3	JP1	JP2	JP3	JP4	JP5
FURUNO	GY-700	DC step 100V 180x 5-wire, open collector	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Anschutz	Standard 2,3	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	Standard 4,6	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#1	#1	#1
	Standard 20	DC step 35V 180X COM(-) 3-wire (+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Yokogawa Navtec (Plaith type)	C-1/1A/2/3 A-55, B-55	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	CMZ-250X/ 300X/500	DC synchronous 360X	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	-	ON	OFF	Remove	#2	-	*	*
		DC step 35V 180X COM (+) 3-wire (-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	CMZ-100/200/ 300 C-1Jr,D-1Z/1/ 3 IPS-2/3	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	CMZ-50 Note 2	step 35V 180X COM (+) 3-wire (-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	Remove	#2	-	*	*
Plaith	NAVIGAT II/III	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 68V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#2	#1	#1
Tokimec (Sperry type)	ES-1/2/11 GLT-101/102/ 103/106K/107	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 36x	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	ES-11A/110 TG-200 PR222R/2000 PR237L/H GM 21	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 22V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	MK-14 MOD-1/2/T NK-EN,NK-EI	DC step 70V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	SR-130/140	DC step 70V 180x 5-wire, open collector	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-100/5000 PR-357/130/ 140, ES-17 GLT-201/202/ 203	DC step 70V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-6000	DC step 24V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	GM-11	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 90X	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	SR-120,ES-16 MK-10/20/30	DC step 35V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Kawasaki	GX-81	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
Arnbrown	MK-10,MKL-1 SERIES1351, MOD-4	DC step 50V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Robertson	SKR-80	DC step 35V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2



Note1) \*: Set JP4 and JP5 according to the voltage of the external power supply.  
 Note 2) If CMZ-50 has 35VDC, set JP1 to #4, #5, #6.

NOTE 1) SUFFICIENT EXTRA CABLINGS SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.


2) REFER TO INSTALLATION INSTRUCTION FOR FABRICATION OF CABLE ENDS.

3) USE M10 BOLTS OR #9 COACH SCREWS FOR FIXING THE UNIT.

4) # : RECOMMENDED SERVICING CLEARANCE.




REMARKS						TYPE		RDP-111	
DRAWN		APPROVED BY: 794		FRI35M2		名称		指示器	
K. M		/K-294		FRI35OM2		NAME			
SCALE		1:20		FRI35OM2				DISPLAY UNIT	
MASS		20 kg		APPLICABLE TO:		BLOCK NO.		DAG NO.	
				(MODEL)					
								C 3308-204	



4-φ15 取付孔  
FIXING HOLES

ケーブル導入口  
CABLE ENTRY φ50



NOTE 1.

※: 推奨サービス空間  
RECOMMENDED SERVICING CLEARANCE

NOTE 2.

種類※※ ANT. TYPE	90cm 型 TYPE	123cm 型 TYPE	200cm 型 TYPE
空中線長 ANT. LENGTH (A)	910mm	1250mm	2000mm
回転直径 DIA. OF ROTATION (B)	1100mm	1400mm	2200mm
質量 MASS	32kg	33kg	37.5kg

※※選択可能な空中線部種類はレーダー型式により異なる。各仕様を参照のこと。  
SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL. SEE INDIVIDUAL SPECIFICATIONS.


取付台の平面度は±1mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1mm.

クランプリング  
Clamp Ring

平座金 F.W.  
(25c)

パッキン  
Packing  
(25c)

ケーブル導入口詳細  
DETAIL OF CABLE ENTRY



4-M4×10

銅バンドまたは編みシールド  
Copper Band or Braided Shield

NOTE 3.

内側シールド  
Inner Shield

装甲(装甲付ケーブルの場合)  
Armor (if provided)

REMARKS

XN1/2/3

TYPE

RSB0063/C2P7N2N/C2P8N2N

名称

空中線部

DRAWN

APPROVED

K.M

FR1510M2

FR2110

NAME

RADAR SCANNER UNIT

SCALE

1/10

MASS

kg

APPLICABLE TO:



(MODEL)

BLOCK NO.

DWG NO.

C3237-001-

U




NOTE 1.

※: 推奨サービス空間  
RECOMMENDED SERVICING CLEARANCE

NOTE 2.



種類** ANT. TYPE	123cm 型 TYPE	200cm 型 TYPE
空中線長 ANT. LENGTH (A)	1250mm	2000mm
回転直径 DIA. OF ROTATION (B)	1400mm	2200mm
質量 MASS	35kg	40kg



NOTE 3.

※※選択可能な空中線部種類はレーダー型式により異なる。各仕様を参照のこと。  
SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL. SEE INDIVIDUAL SPECIFICATIONS.  
取付台の平面度は±1mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1mm.

REMARKS XN2/3				TYPE RSB0014/RSB0064
				名称 空中線部
DRAWN K.M	APPROVED N.V. 7/94 K.C.E.D.A.	FR1525M2 FR2120		NAME RADAR SCANNER UNIT
SCALE 1/10	MASS kg	APPLICABLE TO: (MODEL)	BLOCK NO.	DWG NO. C3290-004-J



NOTE 1.

※: 推奨サービス空間  
RECOMMENDED SERVICING CLEARANCE


NOTE 2.

種類※※ ANT. TYPE	200cm 型 TYPE (XN-3A)	240cm 型 TYPE (XN-4A)
空中線長 ANT. LENGTH (A)	2070mm	2570mm
回転直径 DIA. OF ROTATION (B)	2200mm	2700mm
質量 MASS	36.5 kg	38.5kg

※※選択可能な空中線部種類はレーダー型式により異なる。各仕様を参照のこと。  
SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL. SEE INDIVIDUAL SPECIFICATIONS.

取付台の平面度は±1mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1mm.

NOTE 3.



REMARKS  
XN3A/4A

TYPE  
RSB0063/C2P7N2N/C2P8N2N

名称  
空中線部

DRAWN  
K.M

APPROVED

FR1510M2  
FR2110

NAME

RADAR SCANNER UNIT

SCALE

1/1C

MASS

kg

APPLICABLE TO;  
(MODEL)

BLOCK NO.

DWG NO.



C3249-011- P

A

B

C

D




NOTE 1.

※ 推奨サービス空間  
RECOMMENDED SERVICING CLEARANCE

NOTE 2.

種類※ ANT. TYPE	200cm 型 TYPE (XN-3A)	240cm 型 TYPE (XN-4A)
空中線長 ANT. LENGTH (A)	2070mm	2570mm
回転直径 DIA. OF ROTATION (B)	2200mm	2700mm
質量 MASS	39kg	42kg



NOTE 3.

※選択可能な空中線部種類はレーダー型式により異なる。各仕様を参照のこと。  
SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL. SEE INDIVIDUAL SPECIFICATIONS.

取付台の平面度は±1mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1mm.

REMARKS XN3A/4A		TYPE RSB0014/RSB0064	
DRAWN K.M		名称 空中線部	
APPROVED NOV 2 '84 KEDA		NAME RADAR SCANNER UNIT	
SCALE 1/10	MASS kg	APPLICABLE TO: (MODEL) FR1525M2 FR2120	BLOCK NO. DWG NO. C3290-003- J




A

B

C

D



**注意:**

1. 電蝕防止のため、組立時にボルト、ナット、ワッシャ及びフランジ面の Oリング溝外側の部分に支給のシリコンシーラント(無酸性)を塗布する。 Oリング及び Oリングの溝には塗布しないこと。
2. Oリングに傷をついたり、ゴミを付着させないように注意のこと。
3. Oリング及びスキャナカバーのパッキンにはグリースを使用すること。 シリコンシーラントは使用不可。

**NOTE:**


1. APPLY SILICONE SEALANT (SUPPLIED, NON-ACID TYPE) ON BOLTS, NUTS, WASHER AND WAVEGUIDE FLANGE OUTSIDE O-RING GROOVE TO AVOID ELECTRICAL CORROSION. (DO NOT APPLY SEALANT TO O-RINGS AND O-RING GROOVES.)
2. DO NOT PINCH O-RING AND KEEP IT CLEAN.
3. FOR PACKINGS OF SCANNER COVERS AND O-RINGS, DO NOT USE SILICONE SEALANT, BUT RATHER USE GREASE.

No.	名称 NAME	型式 SPECIFICATION	数量 Q'ty	
			*1	*2
1	Oリング O-RING	ASS68-125	2	
2	六角ボルト HEX. BOLT	M4 x 16 (SUS304)	8	-
	六角ワッシャ (B) HEX. BOLT (B) (WASHER HEAD)	M4 x 16 (SUS304)	-	8
3	平座金 SPRING WASHER	FOR M4用 (SUS304)	8	-
4	平座金 FLAT WASHER	FOR M4用 (SUS304)	8	-
5	六角ボルト HEX. BOLT	M8 x 25 (SUS304)	4	-
	六角ワッシャ (A) HEX. BOLT (A) (WASHER HEAD)	M6 x 25	-	6
6	平座金 SPRING WASHER	FOR M8用 (SUS304)	4	-
7	平座金 FLAT WASHER	FOR M8用 (SUS304) RSG-1002-0	4	-
8	六角ボルト HEX. BOLT	M8 x 30 (SUS304)	4	6
9	平座金 FLAT WASHER	FOR M8用 (SUS304)	8	12
10	平座金 SPRING WASHER	FOR M8用 (SUS304)	4	6
11	六角ナット HEX. NUT	M8 (SUS304)	4	6
12	六角ワッシャ (B) HEX. BOLT (B) (WASHER HEAD)	M4 x 25	-	2
13	導波管押え W/G CLAMP	RSB-2006-1	-	1
14	導波管パッキン W/G PACKING	RSB-2008-0	-	1

\*1: 900/1230mm アンテナ用 (XN-1/2)  
FOR 900/1230mm RADIATOR (XN-1/2)

\*2: 2000mm アンテナ (XN-3) 用  
FOR 2000mm RADIATOR (XN-3)

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	MAY. 25. 77	三角法 THIRD ANGLE PROJECTION			
検図 CHECKED	MAY. 25. 77	尺度 SCALE	名称 TITLE 空中線部組立図 SCANNER UNIT ASSEMBLING		
製図 DRAWN	25. 5. 77	重量 WEIGHT	空中線長 ANT. LENGTH: 900, 1230 & 2000mm (XN-1/2/3)		
		kg	図番 DWG.NO. C3237-025-J		



No.	名称 NAME	型式 SPECIFICATION	数量 Q'TY
1	O-RING	ASS68-125	2
2	六角セムス(B) HEX. BOLT(B) (WASHER HEAD)	M4x16 (SUS304)	8
3	六角ボルト HEX. BOLT	M8x35 (SUS304)	4
4	バネ座金 SPRING WASHER	FOR M8用 (SUS304)	4
5	平座金 FLAT WASHER	FOR M8用 (SUS304)	4
6	六角ボルト HEX. BOLT	M8x30 (SUS304)	4
7	平座金 FLAT WASHER	FOR M8用 (SUS304)	8
8	バネ座金 SPRING WASHER	FOR M8用 (SUS304)	4
9	六角ナット HEX. NUT	M8 (SUS304)	4
10	六角ボルト HEX. BOLT	M4x30 (SUS304)	2
11	バネ座金 SPRING WASHER	FOR M4用 (SUS304)	2
12	平座金 FLAT WASHER	FOR M4用 (SUS304)	2
13	導波管押え W/G CLAMP	RSB-2006-1	1
14	導波管間座 W/G PACKING	03-003-4003-0	1


## 注意:

- 電蝕防止のため、組立時にボルト、ナット、ワッシャ及びフランジ面の  
Oリング溝外側の部分に支給のシリコンシーラント(無酸性)を塗布する。  
Oリング及びOリングの溝には塗布しないこと。
- Oリングに傷をつけたり、ゴミを付着させないように注意のこと。
- Oリング及びスキャナカバーのパッキンにはグリースを使用すること。  
シリコンシーラントは使用不可。


## NOTE:

- APPLY SILICONE SEALANT (SUPPLIED, NON-ACID TYPE) ON  
BOLTS, NUTS, WASHER AND WAVEGUIDE FLANGE OUTSIDE  
O-RING GROOVE TO AVOID ELECTRICAL CORROSION. (DO NOT  
APPLY SEALANT TO O-RINGS AND O-RING GROOVES.)
- DO NOT PINCH O-RING AND KEEP IT CLEAN.
- FOR PACKINGS OF SCANNER COVERS AND O-RINGS, DO NOT  
USE SILICONE SEALANT, BUT RATHER USE GREASE.

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	MAY. 25. '79	三角法 THIRD ANGLE PROJECTION	名称 TITLE	空中線部組立図 SCANNER UNIT ASSEMBLING (XN3A/XN4A)	
検図 CHECKED	MAY. 25. '79	尺度 SCALE			
製図 DRAWN	25. 5. 79	重量 WEIGHT	kg	図番 DWG. NO.	C3249-017-H



REMARKS						TYPE		FR-1505/1510/1525-M2	
DRAWN		APPROVED		FR1525M2		NAME		相互转接图	
K M		1525		FR1510M2		BLACK NO.			
SCALE		1/50		FR1505M2		APPLICABLE TO:		INTERCONNECTION DIAGRAM	
						(MODEL)		C3398-C01C	
						MASS			
						K/g			



TYPE		RDP-111	
名称		指示器 綜合	
NAME		FR1525M2 1B 1	
BLOCK NO.		FR1505M2 1B 1	
APPLICABLE TO:		(when)	
SCALE		K. M.	
DIGITAL		APPROVED 8/27/74	
REMARKS		FR1525M2 1B 1	

TYPE		RDP-111	
名称		指示器 綜合	
NAME		FR1525M2 1B 1	
BLOCK NO.		FR1505M2 1B 1	
APPLICABLE TO:		(when)	
SCALE		K. M.	
DIGITAL		APPROVED 8/27/74	
REMARKS		FR1525M2 1B 1	

A


B

C

4

3

2



NAME	MD-9102: FR-1210M2; MD-9102A: FR-1210M2	TYPE	C2P7N2LC24RPM1/RSB-0063(C36RPM)
CHECKED	Nov. 1 '95 E. KISHIMOTO	名称	空中監視機
APPROVED	Nov. 1 '95 T. SAITO	FR-8051	2B 1
SCALE	Nov. 1 '95 E. OHTA	FR1510M2	2B 1
DATE	Nov. 1 '95	FR1505M2	2B 1
SCALE	1/50	APPLICABLE TO:	(MODEL)
DATE	Nov. 1 '95	MASS	kg
DATE	Nov. 1 '95	SCANNER UNIT	
DATE	Nov. 1 '95	C3398-K01-C	

SCHEMATIC DIAGRAM



U852 

U853 

SCANNER UNIT